

item name	Soprano Metallophone
item number	22200001
item description	SKM 10
sound bar material	metal, specially alloyed
sound bar color	grey
sound bar width	38 mm
sound bars thickness	10 mm
tuning	fundamental tuning
sound bar imprints	In Germany the accentuations for the diatonic C major scale are: c d e f g a h c. In England, the United States and further countries the names are: c d e f g a b c. Solfège music teaching in English-speaking countries uses the syllables: do, re, mi, fa, sol, la, ti. The chart on the last page shows note names and sound bar imprints.
sound bar references	The actual measure of a sound bar can differ slightly from this specifications. The reasons for this are the tuning procedure and the material properties.

item number	29101613	tone	c2	sound bar length	255 mm
item number	29101615	tone	d2	sound bar length	247 mm
item number	29101617	tone	e2	sound bar length	239 mm
item number	29101618	tone	f2	sound bar length	230 mm
item number	29101619	tone	f-sharp2	sound bar length	227 mm
item number	29101620	tone	g2	sound bar length	222 mm
item number	29101622	tone	a2	sound bar length	215 mm
item number	29101623	tone	b-flat2	sound bar length	211 mm

item number	29101624	tone	b2	sound bar length	207 mm
item number	29101625	tone	c3	sound bar length	199 mm
item number	29101627	tone	d3	sound bar length	191 mm
item number	29101629	tone	e3	sound bar length	183 mm
item number	29101630	tone	f3	sound bar length	175 mm
item number	29101631	tone	f-sharp3	sound bar length	170 mm
item number	29101632	tone	g3	sound bar length	168 mm
item number	29101634	tone	a3	sound bar length	159 mm

Arrangement of sound bars

The diagram illustrates the arrangement of sound bars across various octaves. It features musical notation for each bar, including notes and accidentals. Red dots indicate the extent of delivery for each bar. The bars are organized into groups by octave and specific tones.

Legend:

- = extent of delivery
- = extent of delivery
- = extent of delivery

Sound bar imprints (top row): Musical notation for d-flat, e-flat, g-flat, a-flat, h = b-flat, d-flat, e-flat, g-flat, a-flat, h = b-flat, and d-flat.

Accentuations (middle row): Labels for specific tones: d-flat2, e-flat2, g-flat2, a-flat2, b-flat2, d-flat3, e-flat3, g-flat3, a-flat3, b-flat3, and d-flat4.

Sound bar imprints (bottom row): Musical notation for c, d, e, f, g, a, h = b, c, d, e, f, g, a, h = b, and c.