

item name **Soprano Glockenspiel**
 item number 27840501
 item description GSM-D
 sound bar material Steel
 sound bar color brushed silver
 sound bar width 25 mm
 sound bars thickness 3 mm
 tuning fundamental tuning



sound bar imprints In Germany the accentuations for the diatonic C major scale are: c d e f g a h c. In England, the United States and further countries the names are: c d e f g a b c. Solfège music teaching in English-speaking countries uses the syllables: do, re, mi, fa, sol, la, ti. The chart on the last page shows note names and sound bar imprints.

sound bar references The actual measure of a sound bar can differ slightly from this specifications. The reasons for this are the tuning procedure and the material properties.

item number	78281475	tone	c3	sound bar length	120,2 mm
item number	78281675	tone	d3	sound bar length	113,5 mm
item number	78281875	tone	e3	sound bar length	107,2 mm
item number	78281975	tone	f3	sound bar length	104,1 mm
item number	78282075	tone	f-sharp3	sound bar length	101,2 mm
item number	78282175	tone	g3	sound bar length	98,3 mm
item number	78282375	tone	a3	sound bar length	92,9 mm
item number	78282575	tone	b-flat3	sound bar length	90,2 mm

item number	78282775	tone	b3	sound bar length	87,7 mm
item number	78282875	tone	c4	sound bar length	85,2 mm
item number	78283075	tone	d4	sound bar length	80,5 mm
item number	78283275	tone	e4	sound bar length	76,0 mm
item number	78283375	tone	f4	sound bar length	73,8 mm
item number	78283475	tone	f-sharp4	sound bar length	71,7 mm
item number	78283575	tone	g4	sound bar length	69,7 mm
item number	78283775	tone	a4	sound bar length	65,8 mm

Arrangement of sound bars

The diagram illustrates the arrangement of sound bars across various octaves. It features musical notations for notes and their corresponding sound bar imprints. Red dots indicate the extent of delivery for each note.

Legend:

- = extent of delivery
- = extent of delivery
- = extent of delivery

Notes and Imprints:

- Octave 3: d-flat3, e-flat3, c-sharp3, d-sharp3, c3, d3, e3, f3, g3, a3, b3, c4, d4, e4, f4, g4, a4, b4, c5
- Octave 4: g-flat3, a-flat3, b-flat3, f-sharp3, g-sharp3, b-flat3, d-flat4, e-flat4, c-sharp4, d-sharp4, g-flat4, a-flat4, b-flat4, f-sharp4, g-sharp4, b-flat4, d-flat5, c-sharp5