

item name **Soprano Xylophone**
 item number 28710101
 item description SSX 100 INT
 sound bar material Palisano
 sound bar color yellow
 sound bar width 30 mm
 sound bars thickness 15 mm
 tuning standard tuning



sound bar imprints In Germany the accentuations for the diatonic C major scale are: c d e f g a h c. In England, the United States and further countries the names are: c d e f g a b c. Solfège music teaching in English-speaking countries uses the syllables: do, re, mi, fa, sol, la, ti. The chart on the last page shows note names and sound bar imprints.

sound bar references The actual measure of a sound bar can differ slightly from this specifications. The reasons for this are the tuning procedure and the material properties.

item number	29105012	tone	c2	sound bar length	269 mm
item number	29105013	tone	d2	sound bar length	261 mm
item number	29105014	tone	e2	sound bar length	253 mm
item number	29105015	tone	f2	sound bar length	245 mm
item number	29105016	tone	f-sharp2	sound bar length	245 mm
item number	29105017	tone	g2	sound bar length	237 mm
item number	29105018	tone	a2	sound bar length	229 mm
item number	29105027	tone	b-flat2	sound bar length	221 mm

item number	29105029	tone	b2	sound bar length	221 mm
item number	29105030	tone	c3	sound bar length	213 mm
item number	29105031	tone	d3	sound bar length	205 mm
item number	29105032	tone	e3	sound bar length	197 mm
item number	29105033	tone	f3	sound bar length	189 mm
item number	29105034	tone	f-sharp3	sound bar length	189 mm
item number	29105035	tone	g3	sound bar length	181 mm
item number	29105036	tone	a3	sound bar length	173 mm

Arrangement of sound bars

The diagram illustrates the arrangement of sound bars across 15 positions. Each position is associated with a specific tone and its corresponding musical notation. Red dots indicate the extent of delivery for each sound bar. The diagram is organized into four groups of three bars each, with a final single bar at the end.

Legend:

- = extent of delivery
- = extent of delivery
- = extent of delivery

Sound bar imprints:

- Group 1: d-flat2, e-flat2
- Group 2: g-flat2, a-flat2, b-flat2
- Group 3: d-flat3, e-flat3
- Group 4: g-flat3, a-flat3, b-flat3
- Group 5: d-flat4

Accentuations:

- Group 1: c-sharp2, d-sharp2
- Group 2: f-sharp2, g-sharp2, b-flat2
- Group 3: c-sharp3, d-sharp3
- Group 4: f-sharp3, g-sharp3, b-flat3
- Group 5: c-sharp4

Notes:

- c2, d2, e2, f2, g2, a2, b2, c3, d3, e3, f3, g3, a3, b3, c4
- c'', d'', e'', f'', g'', a'', h = b'', c''', d''', e''', f''', g''', a''', h = b''', c''''