

item name **Soprano Xylophone**
 item number 28711001
 item description SSX 1.1 DE
 sound bar material Pao Rosa, FSC™
 sound bar color natural
 sound bar width 30 mm
 sound bars thickness 15 mm
 tuning standard tuning



sound bar imprints In Germany the accentuations for the diatonic C major scale are: c d e f g a h c. In England, the United States and further countries the names are: c d e f g a b c. Solfège music teaching in English-speaking countries uses the syllables: do, re, mi, fa, sol, la, ti. The chart on the last page shows note names and sound bar imprints.

sound bar references The actual measure of a sound bar can differ slightly from this specifications. The reasons for this are the tuning procedure and the material properties.

item number	29104912	tone	c2	sound bar length	269 mm
item number	29104913	tone	d2	sound bar length	261 mm
item number	29104914	tone	e2	sound bar length	253 mm
item number	29104915	tone	f2	sound bar length	245 mm
item number	29104916	tone	f-sharp2	sound bar length	245 mm
item number	29104917	tone	g2	sound bar length	237 mm
item number	29104918	tone	a2	sound bar length	229 mm
item number	29104926	tone	b-flat2	sound bar length	221 mm

item number	29104928	tone	b2	sound bar length	221 mm
item number	29104930	tone	c3	sound bar length	213 mm
item number	29104931	tone	d3	sound bar length	205 mm
item number	29104932	tone	e3	sound bar length	197 mm
item number	29104933	tone	f3	sound bar length	189 mm
item number	29104934	tone	f-sharp3	sound bar length	189 mm
item number	29104935	tone	g3	sound bar length	181 mm
item number	29104936	tone	a3	sound bar length	173 mm

Arrangement of sound bars

The diagram illustrates the arrangement of sound bars across various octaves. It features musical notation for notes and their delivery extent (indicated by red dots). The notes are organized into groups for each octave, with specific notes highlighted in grey boxes to indicate delivery extent.

Legend:

- = extent of delivery
- = extent of delivery
- = extent of delivery

Notes and Delivery Extent:

- Octave 2:** c2, d2, e2, f2, g2, a2, b2. Delivery extent for c2, d2, e2, f2, g2, a2, b2.
- Octave 3:** c3, d3, e3, f3, g3, a3, b3, c4. Delivery extent for c3, d3, e3, f3, g3, a3, b3, c4.

Sound Bar Imprints:

- Octave 2: d-flat2, e-flat2, g-flat2, a-flat2, b-flat2.
- Octave 3: d-flat3, e-flat3, g-flat3, a-flat3, b-flat3, d-flat4.