

|                      |   |
|----------------------|---|
| item name            | <b>Chime Bar - Metallophone</b>   |
| item number          | 22000722  |
| item description     | KS 40 L BW G1   |
| sound bar material   | metal, specially alloyed  |
| sound bar color      | dark green  |
| sound bar width      | 40 mm   |
| sound bars thickness | 6 mm  |
| tuning               | standard tuning   |
| sound bar imprints   | In Germany the accentuations for the diatonic C major scale are: c d e f g a h c. In England, the United States and further countries the names are: c d e f g a b c. Solfège music teaching in English-speaking countries uses the syllables: do, re, mi, fa, sol, la, ti. The chart on the last page shows note names and sound bar imprints. |
| sound bar references | The actual measure of a sound bar can differ slightly from this specifications. The reasons for this are the tuning procedure and the material properties.  |

item number **29101006**tones **g1**sound bar length **232 mm**

---

### Arrangement of sound bars

|                     |    |                     |                     |                     |                    |                     |     |                     |                     |                     |                    |                     |                               |      |                               |
|---------------------|----|---------------------|---------------------|---------------------|--------------------|---------------------|-----|---------------------|---------------------|---------------------|--------------------|---------------------|-------------------------------|------|-------------------------------|
|                     |    |                     |                     |                     |                    |                     |     |                     |                     |                     |                    |                     | <b>sound bar imprints</b>     |      |                               |
| d-flat1<br>c-sharp1 |    | e-flat1<br>d-sharp1 | g-flat1<br>f-sharp1 | a-flat1<br>g-sharp1 | b-flat1<br>b-flat1 | d-flat2<br>c-sharp2 |     | e-flat2<br>d-sharp2 | g-flat2<br>f-sharp2 | a-flat2<br>g-sharp2 | b-flat2<br>b-flat2 | d-flat3<br>c-sharp3 | <b>● = extent of delivery</b> |      |                               |
| c1                  | d1 | e1                  | f1                  | g1                  | a1                 | b1                  | c2  | d2                  | e2                  | f2                  | g2                 | a2                  | b2                            | c3   | <b>accentuations</b>          |
|                     |    |                     |                     | ●                   |                    |                     |     |                     |                     |                     |                    |                     |                               |      | <b>● = extent of delivery</b> |
|                     |    |                     |                     |                     |                    |                     |     |                     |                     |                     |                    |                     |                               |      | <b>sound bar imprints</b>     |
| c'                  | d' | e'                  | f'                  | g'                  | a'                 | h = b'              | c'' | d''                 | e''                 | f''                 | g''                | a''                 | h = b''                       | c''' |                               |