

Artikelname	Tenor-Alt Glockenspiel
Artikelnummer	21100601
Artikelbezeichnung	TAGL 2
Klangplatten Material	Metall, speziallegiert
Klangplatten Farbe	aluminium poliert
Klangplatten Breite	20 mm
Klangplatten Stärke	4 mm
Stimmung	Grundton-Stimmung
Klangplatten Aufdrucke	In Deutschland lauten die Tonbezeichnungen für die diatonische C-Dur-Tonleiter c, d, e, f, g, a, h, c. In England, USA und weiteren Ländern jedoch c, d, e, f, g, a, b, c. Die Solfège-Musiklehre verwendet üblicherweise in englischsprachigen Ländern: do, re, mi, fa, sol, la, ti, do. Die Grafik auf der letzten Seite zeigt Tonbezeichnungen und Klangplattenaufdrucke.
Klangplatten Hinweise	Das tatsächliche Maß einer Klangplatte kann von diesen Maßangaben geringfügig abweichen. Gründe dafür sind der Stimmvorgang und die Materialeigenschaften.

Artikelnummer	783 002 78	Ton	cis2	Klangplatten Länge	197 mm
Artikelnummer	783 004 78	Ton	dis2	Klangplatten Länge	185 mm
Artikelnummer	783 009 78	Ton	gis2	Klangplatten Länge	161 mm
Artikelnummer	783 014 78	Ton	cis3	Klangplatten Länge	138 mm
Artikelnummer	783 016 78	Ton	dis3	Klangplatten Länge	130 mm
Artikelnummer	783 021 78	Ton	gis3	Klangplatten Länge	112 mm
Artikelnummer	783 026 78	Ton	cis4	Klangplatten Länge	97 mm

Anordnung der Klangplatten

The diagram illustrates the arrangement of sound plates for a piano, showing the layout of notes on four plates and their corresponding positions on a piano keyboard.

Plate 1 (Left): Notes d^b and e^b are printed above the notes $c^{\sharp''}$ and $d^{\sharp''}$. A red dot is located below $c^{\sharp''}$. Below the plate, the notes $des2$ and $es2$ are listed, with $cis2$ and $dis2$ below them.

Plate 2: Notes g^b , a^b , and $h = b^b$ are printed above the notes $f^{\sharp''}$, $g^{\sharp''}$, and $a^{\sharp''}$. A red dot is located below $g^{\sharp''}$. Below the plate, the notes $ges2$, $as2$, and $b2$ are listed, with $fis2$, $gis2$, and $b2$ below them.

Plate 3: Notes d^b and e^b are printed above the notes $c^{\sharp'''}$ and $d^{\sharp'''}$. A red dot is located below $c^{\sharp'''}$. Below the plate, the notes $des3$ and $es3$ are listed, with $cis3$ and $dis3$ below them.

Plate 4 (Right): Notes g^b , a^b , and $h = b^b$ are printed above the notes $f^{\sharp'''}$, $g^{\sharp'''}$, and $a^{\sharp'''}$. A red dot is located below $g^{\sharp'''}$. Below the plate, the notes $ges3$, $as3$, and $b3$ are listed, with $fis3$, $gis3$, and $b3$ below them.

Plate 5 (Far Right): Note d^b is printed above the note $c^{\sharp''''}$. A red dot is located below $c^{\sharp''''}$. Below the plate, the notes $des4$ and $cis4$ are listed.

Keyboard: The notes $c2$, $d2$, $e2$, $f2$, $g2$, $a2$, $h2$, $c3$, $d3$, $e3$, $f3$, $g3$, $a3$, $h3$, and $c4$ are shown in a row.

Legend:

- Klangplatten Aufdrucke** (Sound plate prints)
- = Lieferumfang** (Red dot = delivery range)
- Tonbezeichnungen** (Pitch designations)
- = Lieferumfang** (Red dot = delivery range)
- Klangplatten Aufdrucke** (Sound plate prints)